


MASTECH® MS8360G

DIGITAL MULTIMETER USER MANUAL



CONTENTS

1. GENERAL INSTRUCTIONS.....	1
1.1 Precaution safety measures	1
1.1.1 Preliminary	1
1.1.2 During use	2
1.1.3 Symbols.....	4
1.1.4 Instructions.....	4
1.2 Protection mechanisms.....	5
2. DESCRIPTION	5
2.1 Instrument Familiarization.....	5
2.2 LCD Display.....	7
2.3 Keypad.....	8
2.4 Terminals.....	11
2.5 Accessories.....	11
3. FUNCTION DESCRIPTION.....	12
3.1 General Functions.....	12
3.1.1 DATA HOLD mode.....	12
3.1.2 Battery saver	12
3.1.3 Non-Contact AC.....	12
Voltage detection	
3.2 Measurement Functions.....	13
3.2.1 AC and DC	
Voltage measurement.....	13
3.2.2 Resistance measurement.....	14
3.2.3 Diode Test	15
3.2.4 Continuity Check.....	16

CONTENTS

3.2.5 Capacitance measurement.....	17
3.2.6 Transistor measurement.....	18
3.2.7 Frequency measurement.....	18
3.2.8 Temperature measurement.....	19
3.2.9 Current measurement.....	19
4. TECHNICAL SPECIFICATIONS	21
4.1 General specifications	21
4.2 Measurement specifications.....	22
4.2.1 DC Voltage.....	22
4.2.2 AC Voltage	22
4.2.3 Frequency.....	23
4.2.4 Resistance.....	23
4.2.5 Diode	23
4.2.6 Audible continuity.....	24
4.2.7 Transistor.....	24
4.2.8 Temperature.....	24
4.2.9 Capacitance.....	25
4.2.10 DC Current.....	25
4.2.11 AC Current.....	26
5. MAINTENANCE	26
5.1 General Maintenance	27
5.2 Battery Replacement.....	27

1. GENERAL INSTRUCTIONS

This instrument complies with IEC 61010-1, CAT. III 600V overvoltage standards. See Specifications.

To get the best service from this instrument, read carefully this user's manual and respect the detailed safety precautions.

International symbols used on the Meter and in this manual are explained in chapter 1.1.3

1.1 Precautions Safety Measures

1.1.1 Preliminary

* Measurement category III is for measurements performed in the building installation.

NOTE: Examples are measurements on distribution boards, circuit-breakers, wiring, including cables, bus-bars, junction boxes, switches, socket-outlets in the fixed installation, and equipment for industrial use and some other equipment, for example, stationary motors with permanent connection to the fixed installation.

* Measurement category II is for measurements performed on circuits directly connected to the low voltage installation.

NOTE: Examples are measurements on household appliances, portable tools and similar equipment.

* Measurement category I is for measurements performed on circuits not directly connected to MAINS.

NOTE: Examples are measurements on circuits not derived from MAINS, and specially protected (internal) MAINS derived circuits. In the latter case, transient stresses are variable; for that reason, requires that the transient withstand capability of the equipment is made known to the user.

* When using this Multimeter, the user must observe all normal safety rules concerning:

- protection against the dangers of electric current.
- protection of the Multimeter against misuse.

* For your own safety, only use the test probes supplied with the instrument. Before use, check that they are in good condition.

1.1.2 During use

* If the meter is used near noise generating equipment, be aware that display may become unstable or indicate large errors.

* Do not use the meter or test leads if they look damaged.

* Use the meter only as specified in this manual; otherwise, the protection provided by the meter may be impaired.

* Use extreme caution when working around bare conductors or bus bars.

* Do not operate the meter around explosive gas, vapor, or dust.


* Verify a Meter's operation by measuring a known voltage. Do not use the Meter if it operates abnormally. Protection may be impaired. When in doubt, have the Meter serviced.

* Uses the proper terminals, function, and range for your measurements.

* When the range of the value to be measured is unknown, check that the range initially set on the multimeter is the highest possible or, wherever possible, choose the autoranging mode.








* To avoid damages to the instrument, do not exceed the maximum limits of the input values shown in the technical specification tables.

- * When the multimeter is linked to measurement circuits, do not touch unused terminals.
- * Caution when working with voltages above 60Vdc or 30Vac rms. Such voltages pose a shock hazard.
- * When using the probes, keep your fingers behind the finger guards.
- * When making connections, connect the common test lead before connecting the live test lead; when disconnecting, disconnect the live test lead before disconnecting the common test lead.
- * Before changing functions, disconnect the test leads from the circuit under test.
- * For all dc functions, including manual or auto-ranging, to avoid the risk of shock due to possible improper reading, verify the presence of any ac voltages by first using the ac function. Then select a dc voltage range equal to or greater than the ac range.
- * Disconnect circuits power and discharge all high-voltage capacitors before testing resistance, continuity, diodes, or capacitance.
- * Never perform resistance or continuity measurements on live circuits.
- * Before measuring current, check the meter's fuse and turn off power to the circuit before connecting the meter to the circuit.
- * In TV repair work, or when carrying out measurements on power switching circuits, remember that high amplitude voltage pulses at the test points can damage the multimeter. Use of a TV filter will attenuate any such pulses.
- * Use the 9V NEDA battery, properly installed in the Meter's battery case, to power the Meter.

- * Replace the battery as soon as the battery indicator () appears. With a low battery, the Meter might produce false readings that can lead to electric shock and personal injury.
- * Do not measure voltages above 600V in Category III installations.
- * Do not operate the Meter with the case (or part of the case) removed.

1.1.3 Symbols:

Symbols used in this manual and on the instrument:

	Caution: refer to the instruction manual. Incorrect use may result in damage to the device or its components.
	AC (Alternating Current)
	DC (Direct Current)
	Earth ground
	Double insulated
	Fuse
	Conforms to European Union directives

1.1.4 Instructions

- * Remove test leads from the Meter before opening the Meter case or battery cover.
- * When servicing the Meter, use only specified replacement parts.
- * Before opening up the instrument, always disconnect from all sources of electric current and make sure you are not charged with static electricity, which may destroy internal components.

- * Any adjustment, maintenance or repair work carried out on the meter while it is live should be carried out only by appropriately qualified personnel, after having taken into account the instructions in this present manual.
- * A "qualified person" is someone who is familiar with the installation, construction and operation of the equipment and the hazards involved. He is trained and authorized to energize and de-energize circuits and equipment in accordance with established practices.
- * When the instrument is opened up, remember that some internal capacitors can retain a dangerous potential even after the instrument is switched off.
- * If any faults or abnormalities are observed, take the instrument out of service and ensure that it cannot be used until it has been checked out.
- * If the meter is not going to be used for a long time, take out the battery and do not store the meter in high temperature or high humidity environment.


1.2 Protection mechanisms

- * Fused by the fuse (FF400mA/1000V) during capacitance, Inductance, mA and hFE measurements.
- * A PTC resistor protects against permanent over voltages of up to 250V during resistance, continuity and diode test measurements.

2. DESCRIPTION

2.1 Instrument Familiarization

FRONT PANEL



- | | | |
|------------------------|----------------|------------------|
| 1. Voltage alert area | 3. LCD display | 5. Rotary switch |
| 2. Voltage alert light | 4. Keypad | 6. Terminals |

2.2 LCD Display

See Table 1 indicated for information about the LCD display.




Figure 1. Display
Table 1. Display Symbols

Symbol	Meaning
	The battery is low. ⚠ Warning: To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator appears.
-	Indicates negative readings.
AC 	Indicator for ac voltage or current. AC voltage and current are displayed as the average of the absolute value of the input, calibrated to indicate the equivalent rms value of a sine wave.
DC 	Indicator for dc voltage or current.
	The Meter is in the Diode Test mode
AUTO	Auto ranges and auto power off
	The Meter is in the Continuity Check mode.
H	The Meter is in the Data Hold mode.

Table 1. Display Symbols (continued)


°C or °F	°C: Celsius scale. The unit of temperature. °F: Fahrenheit scale.
V, mV	V: Volts. The unit of voltage. mV: Millivolt. 1×10^{-3} or 0.001 volts.
A, mA, μA	A: Amperes (amps). The unit of current. mA: Milliamp. 1×10^{-3} or 0.001 amperes. μA: Microamp. 1×10^{-6} or 0.000001 amperes
Ω, KΩ, MΩ	Ω: Ohm. The unit of resistance. kΩ: Kilohm. 1×10^3 or 1000 ohms. MΩ: Megohm. 1×10^6 or 1,000,000 ohms.
MkHz	Hz: Hertz, the unit of frequency KHz: Kilohertz. 1×10^3 or 1000 hertz. MHz: Milohertz, 1×10^6 or 1000000 hertz
μF, nF	F: Farad. The unit of capacitance. μF: Microfarad. 1×10^{-6} or 0.000001 farads. nF: Nanofarad. 1×10^{-9} or 0.00000001 farads

2.3 Keypad

See Table 2 indicated for information about the keypad operations.

Table 2. Keypad

FUNC	"FUNC" key is the function select key that acts with trigger. Use the key as switch of DC/AC, Resistance/Continuity/Diode/capacitance and °C/°F.
-------------	--

	<p>Press "HOLD" to enter and exit the hold mode in any mode. That act with trigger. When press and holding this key for more than 2secs , the meter is switched to theback light mode.</p>
<p>MAX/MIN</p>	<p>This key is act with trigger. Press this key once, the maximum value is holding (Will displays 'MAX' symbol in the LCD)and press once again this key, the minimum value on holding(Will displays 'MIN'symbol in the LCD). When press and holding this key for more than 2sec, the meter will be return to the normal mode. After pressing the key, A/D will keep working, and the display value are always updated and kept the maximum or minimum value.</p>
<p>RANGE</p>	<p>It is the auto/manual measurement push key that act with trigger. The default is auto measurement when power is on. To press once time, will switch to manual measurement and 'AUTO' sign displayed on the LCD. If continue to press the key in the top range, the meter will be jump to the lowest range, and recirculating orderly. If press and hold this key Over 2sec, the meter will switch to Auto Measurement mode and 'AUTO' sign will be displayed on the LCD.</p>

<p>REL</p>	<p>Press the "REL" key, you can measure the relative value and 'REL' sign will appears on the LCD display in the relative mode. What is meant by relative value? Press the "REL" key, the meter make the first measured value into a reference value (You must be decide a reference value as the input signal.) , and the meter store the displayed reading as a reference value. The relative measured value that displayed in LCD is achieved by subtracting a reference value from the present reading value. $V_x - V_{ref} = V_{display}$</p>
<p>Hz/Duty</p>	<p>This key acts with trigger.. Press "Hz/Duty "key when frequency mode is in operation, the meter will switch to duty cycle measurement mode. Press this key again to switch to frequency measurement mode also.</p>

2.4 Terminals

See Table 4 indicated for information about the terminals.

Table 4. Terminals

Terminal	Description
COM	Return terminal for all measurements. (Receiving the black test lead or the "com" plug of the special multi-function socket)
→ V Ω Hz% ←	Input for voltage, resistance, frequency, diode and continuity measurements. (Receiving the red test lead).
TEMP μA mA hFE	Input for Temperature, hFE and 0.1μA to 400mA current measurements. (Receiving the red test lead or the "+" plug of the special multi-function socket)
10A	Input for 400mA to 10A current measurements. (Receiving the red test lead)

2.5 Accessories

Delivered with the multimeter:

• User's manual	One piece
• Test leads	One piece
• Carry case	One piece
• "K" type bead Thermocouple	One piece
• Special Multi-function socket	One piece

3. FUNCTION DESCRIPTION

3.1 General Functions

3.1.1 DATA HOLD mode

Data Hold mode makes the meter stop updating the display. Data Hold function can be cancelled by changing the measurement mode, or push **HOLD** key again.

To enter and exit the Data Hold mode:

1. Press **HOLD** key. Fixes the display on the current value, **H** is displayed.
2. A second short press returns the meter to normal mode.

3.1.2 Battery Saver

Turn on the meter. And then The Meter will be turned off automatic after approx. 15 minutes. the buzzer will sound five times before the Meter turn off .

3.1.3 Non Contact AC Voltage detection

Set rotary switch to the $\overset{NCV}{\sim}V$ position and hold the Meter so that the Meter's top is vertically and horizontally centered and contacting the conductor ,when the live voltage > 110V(RMS),the sensing indicator will be on and the buzzer will keep sounding as warning.

Note:

- 1: Even without LED indication, the voltage may still exist. Do not rely on non-contact voltage detector to determine the presence of voltage wire, Detection operation may be subject to socket design, insulation thickness and different type and other factors.
- 2: When the meter input terminals presence voltage, due to the influence of presenced voltage, voltage sensing indicator may also be bright.

- 3: Keep the meter away from electrical noise sources during the tests, i.e., florescent lights, dimmable lights, motors, etc.. These sources can trigger NON-Contact AC Voltage Detection Function and invalidate the test.

3.2 Measurement Functions

3.2.1 AC and DC Voltage Measurement



To avoid electrical shock and/or damage to the instrument, do not attempt to take any voltage measurement that might exceeds 600VDC or 600VAC rms.

To avoid electrical shock and/or damage to the instrument, do not apply more than 600VDC or 600VAC rms between the common terminal and the earth ground.

Voltage is the difference in electrical potential between two points.

The polarity of ac (alternating current) voltage varies over time; the polarity of dc (direct current) voltage is constant.

The Meter's DC voltage ranges are 400.0mV, 4.000V, 40.00V, 400.0V and 600V; AC voltage ranges are 400.0mV(only in range mode),4.000V,40.00V, 400.0V and 600V.

To measure ac or dc voltage:

1. Set rotary switch to the $\approx V$ proper range.
2. Connect the black and red test leads to the **COM** and **V** terminals respectively.
3. Connect the test leads to the circuit being measured.

4. Read the displayed value. The polarity of red test lead connection will be indicated when making a **DCV** measurement.

Note:

Unstable display may occur especially at DC400mV and AC400mV ranges, even though you do not put test leads into input terminals, in this case, if an erroneous reading is suspected, short the V terminal and the COM terminal, and make sure the zero display.

3.2.2 Resistance measurement



To avoid electrical shock and/or damage to the instrument, disconnect circuit power and discharge all high-voltage capacitors before measuring resistance.

Resistance is an opposition to current flow.

The Meter's resistance ranges are 400.0 Ω , 4.000k Ω , 40.00k Ω , 400.0k Ω , 4.000M Ω and 40.00M Ω .

To measure resistance:

1. Set the rotary switch to $\rightarrow \Omega$ proper range.
2. Connect the black and red test leads to the **COM** and **Ω** terminals respectively.
3. Connect the test leads to the circuit being measured and read the displayed value.

Some tips for measuring resistance:

- The measured value of a resistor in a circuit is often different from the resistor's rated value. This is because the Meter's test current flows through all possible paths between the probe tips.

- In order to ensure the best accuracy in measurement of low resistance, short the test leads before measurement and memory the test probe resistance in mind. This necessary to subtract for the resistance of the test leads.
- On 40M Ω ranges, the meter will take a few seconds to stabilize reading. This is normal for high resistance measuring.
- When the input is not connected, i.e. at open circuit, the figure "OL" will be displayed for the over range condition.

3.2.3 Diode Test



To avoid electrical shock and/or damage to the instrument, disconnect circuit power and discharge all high-voltage capacitors before testing diodes.

Use the diode test to check diodes, and other semi-conductor devices. The diode test sends a current through the semiconductor junction, and then measures the voltage drop across the junction; a good silicon junction drops between 0.5V and 0.8V.

To test a diode out of a circuit:

1. Set the rotary switch to $\rightarrow \Omega$ range.
2. Press the **FUNC** key one time to activate Diode Test.
3. Connect the black and red test leads to the **COM** and \rightarrow terminals respectively.
4. For forward-bias readings on any semiconductor component, place the red test lead on the component's anode and place the black test lead on the component's cathode.

5. The meter will show the approx. forward voltage of the diode. If the test lead connection is reversed, only figure "OL" displayed. In a circuit, a good diode should still produce a forward bias reading of 0.5V to 0.8V; however, the reverse-bias reading can vary depending on the resistance of other pathways between the probe tips.

3.2.4 Continuity Check



To avoid electrical shock and/or damage to the instrument, disconnect circuit power and discharge all high-voltage capacitors before testing for Continuity.

Continuity is a complete path for current flow. The beeper sounds if a circuit is complete. These brief contacts cause the Meter to emit a short beep.

To test for continuity:

1. Set the rotary switch to $\rightarrow \Omega$ range.
2. Press the **FUNC** key one time to activate Diode Test.
3. Connect the black and red test leads to the **COM** and Ω terminals respectively.
4. Connect the test leads to the resistance in the circuit being measured.
5. When the test lead to the circuit is below approx. 60 Ω , a continuous beeping will indicate it.

Note:

Continuity test is available to check open/short of the circuit.

3.2.5 Capacitance Measurement



To avoid electrical shock and/or damage to the instrument, disconnect circuit power and discharge all high-voltage capacitors before measuring capacitance. Use the dc voltage function to confirm that the capacitor is discharged.

Capacitance is the ability of a component to store an electrical charge.

The unit of capacitance is the farad (F). Most capacitors are in the nanofarad to microfarad range.

The Meter's capacitance ranges are 40.00nF, 400.0nF, 4.000μF, 40.00μF, 400.0μF and 4000μF.

To measure capacitance:

1. Set the rotary switch to $\rightarrow \Omega$ position. Press the **FUNC** key three times to activate Capacitance Test.
2. Connect the black and red test leads to the **COM** and **⚡** terminals respectively (or you can measure the capacitance by using the special Multi-Function Socket).
3. Connect the test leads to the capacitor being measured and read the displayed value.

Some tips for measuring capacitance:

- The meter may take a few seconds to stabilize reading. This is normal for high capacitance measuring.
- To improve the accuracy of measurements less than 40nF, subtract the residual capacitance of the Meter and leads.

3.2.6 Transistor Measurement



To avoid electrical shock and/or damage to the instrument, do not apply more than 250Vdc or 250Vac rms between the hFE terminal and the COM terminal.

1. Set the rotary switch to **hFE** range.
2. Connect the "**com**" plug and "**+**" plug of the special multi-function socket to the **COM** and **hFE** terminals.
3. Determine whether the transistor to be tested is **NPN** or **PNP** type and locate the Emitter, Base and Collector leads.
4. Insert leads of the transistor into proper holes of the special multi-function socket.
5. The meter will show the approx. **hFE** value at test condition of base current 10μA and Vce 2.8V.

3.2.7 Frequency Measurement



Do not measure Frequency on high voltage (>250V) to avoid electrical shock hazard and/or damage to the instrument.

Frequency is the number of cycles a voltage or current signal completes each second.

To measure frequency:

1. Set the rotary switch to **Hz %** position.
2. Connect the black and red test leads to the **COM** and **Hz** terminals respectively.
3. Connect the test leads to the circuit being measured
4. Read the displayed value.

3.2.8 Temperature Measurement



To avoid electrical shock and/or damage to the instrument, do not apply more than 250Vdc or 250Vac rms between the °C terminal and the COM terminal. To avoid electrical shock, do not use this instrument when voltages at the measurement surface exceed 60v dc or 24v rms. Ac. To avoid damage or burns. Do not make temperature measurements in microwave ovens.

To measure temperature:

1. Set the rotary switch to **TEMP** position.
2. Connect 'K' type thermocouples to terminals, make sure the red and black leads to the TEMP and **COM** terminals respectively
3. Touch the object with the thermocouple probe for measurement.
4. Read the stable reading from LCD.

3.2.9 Current Measurement



To avoid damage to the Meter or injury if the fuse blows, never attempt an in-circuit current measurement where the open-circuit potential to earth is greater than 250V. To avoid damage to the meter, check the meter's fuse before proceeding. Use the proper terminals, function, and range for your measurement. Never place the test leads in parallel with a circuit or component when the leads are plugged into the current terminals.

Current is the flow of electrons through a conductor. The Meter's DC current ranges are 400.0µA, 4000µA, 40.00mA, 400.0mA, 4.000A and 10.00A; AC current ranges are 400.0µA, 4000µA, 40.00mA, 400.0mA, 4.000µA and 10.00A.

To measure current:

1. Turn off the power of the measured circuit.
Discharge all the high voltage capacitors.
2. Set the rotary switch to the proper position.
3. Connect the black test lead to the COM terminal and the red test leads to the mA terminal for a maximum of 400mA. For a maximum of 10A, move the red test lead to the 10A terminal.
4. Break the circuit path to be tested.
Connect the black test leads to the more negative side of the break; connect the red test leads to the more positive side of the break. (Reversing the leads will give a negative reading, but will not damage the Meter.)
5. Turn on the power of the measured circuit, and then read the display. Be sure to note the measurement units at the right side of the display (mA or A). When only the figure "OL" displayed, it indicates overrange situation and the higher range has to be selected.
6. Turn off the power of the measured circuit and discharge all the high voltage capacitors. Remove the test leads and recover the measured circuit.

4. TECHNICAL SPECIFICATIONS

4.1 General Specifications

- Environment conditions:
600V CAT. III
Pollution degree: 2
Altitude < 2000m
Operating temperature:
0~40°C, 32°F~122°F(<80% RH, <10°C noncondensing)
Storage temperature:
-10~60 °C, 14°F~140°F(<70% RH, battery removed)
- Temperature Coefficient:
0.1x(specified accuracy) /°C(<18°C or >28°C)
- MAX. Voltage between terminals and earth ground:
600V AC rms or 600V DC.
- Fuse Protection: mA: fuse (FF400mA/1000V)
A: fuse (FF10A/600V)
- Sample Rate: 3 times/sec for digital data and 30 times/sec for the analog bar.
- Display: 4000 counts with analog bar LCD display.
Automatic indication of functions and symbols.
- Over Range indication: LCD will display "OL".
- Low battery indication: The "E" is displayed when the battery is under the proper operation range.
- Polarity indication: "—" displayed automatically.
- Power source: 9V
- Battery type: NEDA 1604, 6F22, or 006P.
- Dimensions: 195(L) x 92(W) x 55(H) mm.
- Weight: 380g. Approx. (battery included).

4.2 Measurement Specifications

Accuracy is specified for one year after calibration, at operating temperatures of 18°C to 28°C, with relative humidity at 0% to 75%.

Accuracy specifications take the form of:
±(% of Reading + Number of Least Significant Digits)

4.2.1 DC Voltage

Range	Resolution	Accuracy
400mV	0.1mV	±(0.5% of rdg +2 digit)
4V	1mV	
40V	10mV	
400V	100mV	±(0.8% of rdg +2 digits)
600V	1V	

Input impedance: 10MΩ

Max. input voltage: 600Vdc or 600V ac rms.

4.2.2 AC Voltage

Range	Resolution	Accuracy
400mV	0.1mV	±(2% of rdg +3 digits)
2V	1mV	±(0.8% of rdg +3 digits)
20V	10mV	
400V	100mV	
600V	1V	±(1% of rdg +3 digits)

Input impedance: 10MΩ

Max. input voltage: 600Vdc or 600V ac rms.

Frequency Range: 40Hz-400Hz .

Response: Average, calibrated in rms of sine wave

4.2.3 Frequency

Range	Resolution	Accuracy
9.999Hz	0.001Hz	±(0.5% of rdg+2 digits)
99.99Hz	0.01Hz	
999.9Hz	0.1Hz	
9.999kHz	0.001kHz	
99.99kHz	0.01kHz	
999.9kHz	0.1kHz	
9.999MHz	0.001MHz	


Overload protection: 250V dc or 250V ac rms.
Input Voltage range: 200mV-10V ac rms

4.2.4 Resistance

Range	Resolution	Accuracy
400Ω	0.1Ω	±(0.8% of rdg +3 digits)
4kΩ	1Ω	±(0.8% of rdg +1 digit)
40kΩ	10Ω	
400kΩ	100Ω	
4MΩ	1kΩ	
40MΩ	10kΩ	±(1.0% of rdg +2 digits)

Overload protection: 250V dc or 250Vac rms.
Open Circuit Voltage: Less than 700mV.

4.2.5 Diode

Range	Resolution	Function
	1mV	Display read approx. forward voltage of diode

Forward DC Current: approx. 1mA
Reversed DC Voltage: approx. 2.8V
Overload protection: 250Vdc or 250Vac rms.

4.2.6 Audible Continuity

Range	Continuity beeper
o)	≤60Ω

Open circuit voltage: Less than 700mV.
Overload protection: 250Vdc or 250Vac rms.

4.2.7 Transistor

Range	Description	Test Condition
hFE	Display read approx. HFE value (0-1000) of transistor under test (all type).	Base Current approx. 10μA, Vce approx. 2.8V.

4.2.8 Temperature

Range	Resolution	Accuracy
-20°C~0°C	1°C	±(5.0% of rdg+4 digits)
1°C~400°C		±(1.0% of rdg +3 digits)
401°C~1000°C		±(2.0% of rdg +2 digits)

Overload protection: fuse (FF400mA/1000V).
* Temperature specifications do not include thermocouple errors.

4.2.9 Capacitance

Range	Resolution	Accuracy
40nF	0.01nF	±(3.0% of rdg +5 digis)
400nF	0.1nF	
4μF	0.001μF	
40μF	0.01μF	
400μF	0.1μF	
4000μF	1μF	

Overload protection: 250V dc or 250V ac rms

4.2.10 DC Current

Range	Resolution	Accuracy
400μA	0.1μA	±(0.8% of rdg +2 digis)
4000μA	1μA	
40mA	10μA	
400mA	0.1mA	
4A	0.001A	±(1.2% of rdg +2 digis)
10A	0.01A	

Overload protection: fuse (FF400mA/1000V).

10A range fuse(FF10A/600V)

Max. input current:400mA dc or 400mA ac rms for mA range, 10A dc or 10A ac rms for 10A ranges.

For measurements>5A, the measuring time for high current(10A) should be ≤10 second for each measurement and the interval time between two measurement should be greater than 1 minutes ;Above 10A unspecified.

4.2.11 AC Current

Range	Resolution	Accuracy
400μA	0.1μA	±(1.5% of rdg +2 digis)
4000μA	1μA	
40mA	10μA	
400mA	0.1mA	
4A	0.001A	±(2.0% of rdg +2 digis)
10A	0.01A	

Overload protection: Resettable fuse (FF400mA/1000V).
10A range fuse(FF10A/600V)

Max. input current: 400mA dc or 400mA ac rms for mA range, 10A dc or 10A ac rms for 10A ranges.

For measurements>5A, the measuring time for high current(10A) should be ≤10 second for each measurement and the interval time between two measurement should be greater than 1 minutes; Above 10A unspecified.

Frequency Range: 40Hz-400Hz

Response: Average, calibrated in rms of sine wave

5. MAINTENANCE

Do not attempt to repair or service your Meter unless you are qualified to do so and have the relevant calibration, performance test, and service information.

5.1 General Maintenance



To avoid electrical shock or damage to the meter, do not get water inside the case. Remove the test leads and any input signals before opening the case

Periodically wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents.


Dirt or moisture in the terminals can affect readings.

To clean the terminals:

- Turn the meter off and remove all test leads.
- Shake out any dirt that may be in the terminals.
- Soak a new swab with a cleaning and oiling agent (such as WD-40).
- Work the swab around in each terminal. The oiling agent insulates the terminals from moisture-related contamination.

5.2 Battery And Fuse Replacement



To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator () appears.

Use only fuses with the amperage, interrupt, voltage And speed ratings specified FF400mA/1000V Min interrupt rating 10000A FF10A/600V Min interrupt rating 10000A.

Before replacing the battery, disconnect test leads and/or any connectors from any circuit under test, turn the meter off and remove test leads from the input terminals.

To replace the battery (see Figure 2.):

- Turn the meter off.
- Disconnect test leads and/or any connectors from the terminals.
- Use a screwdriver to unscrew the two screws secured on the battery cover.
- Take out the battery cover from the meter.
- Remove the used batteries.
- Replace with the new 9V batteries (6F22).
- Rejoin the battery cover and secure by the two screws.

CAUTION

Using this appliance in an environment with a strong radiated radio-frequency electromagnetic field (approx. 3V/m), may influence its measuring accuracy. The measuring result can be strongly deviating from the actual value.

