

PCE Americas Inc.
711 Commerce Way
Suite 8
Jupiter
FL-33458
USA
From outside US: +1
Tel: (561) 320-9162
Fax: (561) 320-9176
info@pce-americas.com

PCE Instruments UK Ltd.
Units 12/13
Southpoint Business Park
Ensign way
Hampshire / Southampton
United Kingdom, SO31 4RF
From outside UK: +44
Tel: (0) 2380 98703 0
Fax: (0) 2380 98703 9
info@pce-instruments.com

www.pce-instruments.com/english www.pce-instruments.com

Technical Airflow Meter PCE-009

Accurate air flow meter to measure air temperature and velocity with calculation of volume of air current and RS-232 interface for data transfer to a computer, software and cable is included

This air flow meter has a good relation between price and quality and it combines accuracy and versatility with the ability to transfer data directly to a computer. This air air flow meter forms a part of a professional's basic equipment to regulate and test ventilation systems. It air flow meter is also used in research and development projects within institutions. Its fine 8mm point makes it possible to use in areas here there is limited space to measure, such as cooling systems. When a surface area is input into the air flow meter, it will calculate the volume of air current in m³/min. In this way, the capacity of a ventilation can be controlled and it can be used for air conditioning and refrigeration systems. It should be taken into account that when measuring air flow, various measurements should be taken and the average used to represent the air flow reading.

- Measures air velocity and temperature
- Calculates volume of air current as well as average volume of air current
- Can be used for low air velocity
- Different units of measurement: m/s, km/h, ft/min, knots, miles/h
- Large LCD
- Easy to use
- Shows minimum and maximum value
- Save function for minimum and maximum values
- Auto shut-off function to protect battery life
- Has an RS-232 interface for data transfers to acomputer
- Comes with a telescopic sensor, batteries, carrying case, software, RS-232 cable and user's manual

Technical specifications

Measurement range with corresponding unit:

- m/s 0.2 to 20.0

- °C 0.0 to 50.0 (sensor)

Calculation of volume of air current:

- m³/min (CCM) 0 to 36,000

Resolution

- Air velocity 0.1m/s (for remaining units, up to ft/min = 1.0)

- Air temperature 0.1°C

- Volume of air current (CCM) 0.001 to 1m³/min (depending on reading)

Accuracy

- Air velocity ±1% (of measurement range) or ±5%

of the corresponding value

- Air temperature ±0.8°C

- Volume of air current (CCM) calculated value

Measuring quote From 2 sec. to 9 hours

Internal memory 16.000 values

Thermal sensor

- telescopic thermistor /

hot wire sensor

contracted length 280mmextended length 940mmmaximum diameter 12mm

- minimum diameter 8mm (at the leading end)

Interface

RS-232

Software / RS-232 cable

- included, compatible with Windows 95, 98, 2000, XP, for data

transfer

- data can also be exported to MS Excel

Display large 58 x 34mm LCD

Operating conditions device: 0° C to 40° C / <80% r.h.

thermal sensor: 0°C to 50°C / <80% r.h.

Power

4 batteries (1,5V) (or by way of an optional mains adaptor of

9V)

Auto shut-off

yes, 5 minutes to protect battery power

Dimensions device: 203 x 76 x 38mm

thermal sensor: 8mm diameter x 940mm maximum extended

length (only 280mm when contracted)

Enclosure

ABS plastic

Weight

515g

Examples of use of air flow meter PCE-009

Contents

PCE-009 air flow meter with thermal sensor and 1.5m connector cable, RS-232 cable, software, 4 batteries, carrying case and user's manual